



4720 Head Installation Guide


For the head life,we will send one bottle of liquid and syringe with all 4720 printer.

Please follow the following ways to use the liquid.


① Find these parts first




② Fill the liquid to the syringe and flash the head



③ Check the nozzle normal or not



If the nozzle look like this, its normal you and install the head normally



If the nozzle look like this or no liquid come out(mean nozzle block),please make a video to us to confirm.

④If the nozzle is normal,during head installation,you can connect head cable without fill ink first to check the head encoder board light normal or not,if the board show red light please send us photo to confirm.

TIPs: When you fill ink at first time from ink cartridge to head,please use syringe suck ink to damper first then use cleaning function to fill ink to head or the head will easily damage (if you use ink fill function from cartridge to head directly by pump) .